



Rear Strut Bar Installation Guide v1.0 (Dec 2014)

Part No. ECO111-0303

Applications


VW Mk7 Golf, GTI, Golf R
Audi 8V A3, S3

List of Parts Included

- (1) Strut Bar Rod
- (2) Strut Bar Rod Ends
- (2) Rod End Jam Nuts
- (2) Strut Bar Mounts
- (6) M8 x 25mm long bolts
- (6) M8 Washers

List of Required Tools

Flat Head Screwdriver No.1
13mm Socket
No. 6 Allen Socket
No. 8 12 pt Socket
15/16" wrench
21mm Wrench
Torque Wrench



Proper service and repair procedures are vital to the safe, reliable operation of all motor vehicles as well as the personal safety of those performing the repairs. Standard safety procedures and precautions (including use of safety goggles and proper tools and equipment) should be followed at all times to eliminate the possibility of personal injury or improper service which could damage the vehicle or compromise its safety.

STEP

1

Remove the two cargo hooks in the trunk of the car. Pry open the bolt cover using a no. 1 screw driver.



STEP

2

Use a no. 8, 12 point, socket to remove the bolt.



STEP

3

Install the Strut Bar Mounts using M8 Allen head cap screws, 25mm long, and washers. Dab a small amount of Loctite (not included) on the threads.



STEP

4

Install the rodends on to the rod. Note that the left hand thread rod end should be installed on the side of the rod with an "L" stamped on a wrench flat. Leave a quarter inch gap between the rodend and the jam nut. Leave the jam nuts loose for now.



STEP 5

Install the assembled rod on to the mounts using the Allen head cap screws (M8 x 25mm long) and washers. Dab a small amount of Loctite (not included) on the threads. Install and hand tight the bolts. The mounts may need to be slightly rotated and the rod ends may be adjusted to get the proper alignment of the rod to the strut mounts.



STEP 6

Rotate the rod such that the rod ends extend. Stop turning as soon as resistance is felt. Tighten all bolts to 12 ft-lbs (16 Nm). (Access the mount bolt by removing one of the rod end bolts closest to the mount.)



STEP

7

Preload the strut mounts by turning the rod 1/8 to 1/4 turn (45 to 90 deg) in the same the direction as in step 6. Tighten the jam nuts on both ends using a 15/16" wrench. Torque to 15 ft-lbs (20 Nm).



The VW cargo net can be attached to the strut bar mounts as shown.



LIMITED ONE (1) YEAR WARRANTY

Eurocode Tuning, Inc. (EUROCODE) warrants to the original purchaser that our (PRODUCT) will be free of defects in material and workmanship for a period of one (1) year from the date of purchase.

This Warranty applies only to the original purchaser of the PRODUCT. To obtain any warranty service, you must provide EUROCODE with proof of purchase and date of purchase acceptable to EUROCODE, such as a copy of your purchase receipt. This warranty does not cover the removal or reinstallation of the product. EUROCODE will, at its option, repair, replace or refund the purchase price of a defective component, provided you return the defective component during the warranty period, transportation charges prepaid, to Eurocode Tuning's Service Department or a Factory Authorized Service Center.

Attach your name, address, telephone number, a description of the problem, and a copy of your sales receipt. All returns must be accompanied by a Return Goods Authorization (RGA) number and such number shall be written clearly on the outside of the box. RGA numbers may be obtained by calling EUROCODE at 1-310-294-8108. This warranty does not apply to the (i) metal finish or (ii) if the product/component has been damaged by accident, abuse, misuse, collision, modification, misapplication, improper installation, or improper service. This warranty is void if any EUROCODE serial number has been removed or defaced. Commercial or industrial use or application, or any motorsports use voids the warranty.

THE WARRANTY SET FORTH ABOVE IS THE ONLY WARRANTY. THERE ARE NO OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ANY IMPLIED WARRANTY WHICH BY LAW MAY NOT BE EXCLUDED IS LIMITED IN DURATION TO ONE (1) YEAR FROM THE DATE OF ORIGINAL RETAIL PURCHASE OF THE PRODUCT.

No EUROCODE dealer, agent or employee is authorized to make any modification, extension or addition to this

warranty.

EUROCODE SHALL NOT BE LIABLE FOR SPECIAL, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, LOST PROFITS, DOWN TIME OR LOSS OF USE) UNDER ANY LEGAL THEORY, EVEN IF EUROCODE WAS ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

Some states do not allow the exclusion of implied warranties or the exclusion or limitation of liability for incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above limitation or exclusion may not apply to you. This warranty gives you specific legal rights. You may also have other rights that vary from state to state. EUROCODE reserves the right to change Product/component design without notice. In situations in which EUROCODE has changed a Product/component design, EUROCODE shall have no obligation to upgrade or otherwise modify previously manufactured Products/components.

Warranty inquiries and Products returned for warranty service should be sent to:

Eurocode Tuning, Inc.
Customer Service Department
1872 Del Amo Blvd Unit A
Torrance, CA 90501
1-310-294-8108
1-310-212-7141 International Fax